Pipe Support

INTENDED USE

Pipe Clamp to keep pipe in place. Allows for vertical adjustments due to slotted holes and horizontal adjustments due to off-center holes when square hole channels are used. Primarily for CH50 channels.

INSTRUCTION FOR USE

Position the bottom part of the clamp with the perforated plated directly below the pipe.

Remember that by rotating the clamp 180°, you get a 6 mm offset on a per hole basis.

Add two M10 bolts in the precut holes, adjust the plate as desired then tighten with two nuts securely.

Add top part of pipe clamp to the pipe and secure tightly.





