

## INTENDED USE

Heavy Duty (HD) cover clamps for OE ladder straight lengths and fittings where high wind loadings occur.

## INSTRUCTION FOR USE

Covers can be fitted as standard using proprietary cover clamps, and further secured using heavy duty clamps at joints or at set centres.

Before fitting the cover, fit bolts in the cover holes and screw nut in place.

Attach the covers and fasten with proprietary cover clamps on the sides.

Fit the clamp over the covers and attach the the nuts on the HD clamp top.

Fix the sides of the clamps onto the rails with self locking bolts.

For widths 450 mm or more, where the covers are 3 m long, support the centre with an additional HD Clamp to the side rails.

When fitting single vertical covers, use at least one HD clamp in combination with standard clamps to ensure the cover cannot slide.



User Guide for Bolts:  
Recommended Torque

