

INTENDED USE

Installation Jig for the Non-metallic trefoil SmartCleit to allow for easy installation on any support.

INSTRUCTION FOR USE

1. Slide the Jig plates to mate with the cleat-connecting bolts.
2. Make sure both Jig plates are held in place, matching the head of the bolts.
3. Lower the SmartCleit base down on the Jig plates.
4. Place the SmartCleit base (w/Jigs) onto the desired support.
5. Install the SmartCleit base to the support using supplied M10 bolt and appropriate adapter. Tighten with M10 nut to 20 Nm.
6. X-section view to show the Jig holding the bolts in place.
7. Place the SmartCleit upper part over the cables.
8. Install the M10 nuts to secure the cleat together. Note that it might be required to hold the Jig in place by hand. Tighten the 4x M10 bolts/nuts to 9 Nm.
9. Remove the Jig plates.

Note:

For installation close to a wall or the siderail on a ladder, use an appropriate wrench tool.
 For more information about cleat adaptors, please refer to ØI-RD-UG-EN-0436.
 For more information about installation of Non-metallic SmartCleit to various supports, please refer to an appropriate user guide for the specific support.

