

Mekano® - Welded Starter Brackets

INTENDED USE

Welded brackets for supporting Mekano® channels. Please ask for our Best Practice Manual for typical grid solutions. We recommend using our AISI 316L starter brackets which avoids the need to insulate against galvanic corrosion when using stainless steel channels.

INSTRUCTION FOR USE

Measure and mark the position of the brackets.
Debur 50-70 mm with a 2 mm radius to give paint a good key.
Weld. Mask. Leave at least 50 mm from the structure unmasked for painting. A range of plastic masking sleeves is available from Øglænd System. Sandblast/clean and paint the exposed surface. Remove the masking. Starter bracket is ready for use.



Oglaend MultiGrid® System has a wide range of welded starter brackets for beams and also for stringers.

