

INTENDED USE

U-Splice for attaching two 50 mm wide SPB-RF or SPBE cable trays together.

Note that outside L-Splices cannot be used on 50 mm widths.

INSTRUCTION FOR USE

Fit the splice equally over the parts being joined.
Attach loosely with self locking bolts.
Adjust and tighten securely.



User Guide for Bolts:
Recommended Torque