

INTENDED USE

The hinge is used for elevation changes for FTE cable trays. The design allows for 4° locking increments in the SS version. FRP version can be adjusted to any angle needed.

INSTRUCTION FOR USE

Attach the hinge loosely to the siderail.

Fit the centre hole to the hinge. Adjust the angle and add the second bolt in the available hole.

For the FRP hinge, friction is enough to hold the angle. Tighten the self locking screws securely.



User Guide for Bolts:
Recommended Torque