

INTENDED USE

FRP Support channels CH100 can be used to create many different support configurations, and the support channel must be drilled on site to suit the requirement. To help ease installation and drilling various drill jigs are available to ensure that perforations are correctly located.

INSTRUCTION FOR USE

Select the required drill jig.

Drill jig placed on the channel at the required location. Refer to user guide image for assistance in selecting the correct jig for the location.

Firmly hold the jig in place and drill through the required jig perforations.

Remove jig, clean and tidy FRP perforations.

Adjust, bolt together securely.

