

FRP - Support

INTENDED USE

The CH100S Support Channel is normally fixed back to back without the need of special tools, the end of the profile allows easy access to box-section. When access to box-section is limited, a method involving the use of a sleeve nut is available for fixing the channels back-to-back.

INSTRUCTION FOR USE

Normal Connection

- 1. Place the drill jig at required location.
- 2. Use drill jig 87050 to drill required perforations.
- 3. Clean and tidy perforations.
- 4. Fasten bolts sets through perforations.

Limited access to box-section: Sleeve nut connection

- Place the drill jig at required location.
- 2. Use drill jig 87050 to drill required perforations.
- 3. Use Granlund drill bit or similar to drill box section for sleeve nut. (Granlund bits: 1F-10,0, 1DS-10 and 1N-20,0)
- 4. Clean and tidy perforations.
- 5. Insert sleeve nut through cut out box section.
- 6. Insert M10 bolt through sleeve from backside of channel.
- 7. Fasten remaining bolt sets through remaining perforations.



User Guide for Bolts: Recommended Torque

We recommened a minimum length of 30 mm for bolts.

For more info on use of drill jig see User Guide ØI-RD-UG-EN-0297.

Normal Connection:

Easy access to the channels box-section allows all bolts to be fastened without special tools. For more information on U-frame support see User Guide ØI-RD-UG-EN-0383



