

## INTENDED USE

Standard Flat Elbow 45° and 90° with integrated splice connectors. Standard radius is 75 mm.

## INSTRUCTION FOR USE

1. Bend the integrated splice connector by hand to fit inside Cable Tray.
2. Slide Flat Elbow inside Cable Tray.
3. Repeat steps 1 and 2, to fit the Cable Tray on the other side. The Flat Elbow is now situated inside the two cable trays.
4. Attach the integrated splice connectors to the 2 cable trays loosely with self locking bolts. If the Cable Tray width is 200 mm or wider, attach the bottoms together with self locking bolts.
5. Adjust and tighten securely.

