

INTENDED USE

The hinge is used for elevation changes for LOE ladders. The design allows for full adjustment of the angle. The hinge can also be bent to create T-junctions and exits from Cable Ladder sides.

INSTRUCTION FOR USE

- Bend the hinge if required to suit.
- Attach the hinge loosely to the rails.
- Adjust and tighten the bolts on the Ladder.
- Check and adjust the angle, and tighten the centre bolt securely.



User Guide for Bolts:
Recommended Torque