USER GUIDE · WELDED STARTER BRACKETS FOR CH50-T & CH100-T SYSTEM



Mekano® - Welded Starter Brackets

INTENDED USE

Highly versitile welded starter brackets compatible with Mekano® channels CH50-2T and CH100-2T channels in all thicknesses. Suitable for square and rectangular hole patterns, and particularly useful for traverse support. Can be welded horizontally to stringers. The sides of the bracket are de-burred ready for paint in accordance with Norsok standard. With hole for safety line hook.

INSTRUCTION FOR USE

Measure and mark the position of the brackets.

- Weld.
- Mask. Leave at least 50 mm from the structure unmasked for painting.
- Sandblast/clean and paint the exposed surface.
- Remove the masking.
- Starter bracket is ready for use.

Plastic masking sleeves for easy masking for sand blasting and painting to leave a clean earthing surface. Available to suit all starter lengths: 140, 200 & 300 mm.







