

INTENDED USE

UNO bracket for bracing under channels, for example with cantilever supports. Available in 45° or 30/60° support angles.

INSTRUCTION FOR USE

Channel open at the bottom:

Fix UNO nuts or UNO card in the channel. Attach the bracing bracket to the underside of the cantilever arm, and onto the vertical support. Use a UNO washer between the bracing and the arm. Adjust and tighten securely.

Channel open at the top

Attach the bracing bracket to the underside of the cantilever arm using a self locking bolt. Fix the cantilever onto the vertical support. Use a UNO washer between the bracing and the arm. Adjust and tighten securely.

