

INTENDED USE

To be used with short clamped shoes to provide an anchor function or Line guide + Hold down with 2 mm gap.

For clamped shoes with 10 mm thick Base Plate.

INSTRUCTION FOR USE

For 2 mm gap, use both plates and install as shown.

For anchor function, remove lower plate part and install directly onto the baseplate of the shoe. Tighten bolts so that the shoe is secured in all directions by friction.

For CH 100-4 use M10x130 Hex bolt for all.



User Guide for Bolts:
Recommended Torque